

digiglass™ digifilm™

care and maintenance



Film Drying out and Curing time:

- 1) Can take up to 4 months.
- 2) Directly after fitting is completed, the film should not be touched for 48 hours. There will be a residue of slip solution which will allow the film to move. During this period a chemical reaction will commence, which will make the film begin to stick to the glass.
- 3) If the initial squeegee of the film during the installation has not managed to remove all the solution then a small residue may remain trapped. Initially this may cause bubbles or a slightly cloudy look to the film. These will dissipate and the cloudy look disappear. Do not attempt to pierce the film to drain the water, as this will damage the film and negate the warranty.
- 4) NB. The curing process with glass is a constant chemical reaction. It continues for as long as the film is on the glass. It does not reach a certain point and stop after a period of time.

Care & Maintenance - Cleaning:

- 1) The film should not be cleaned for at least 30 days after fitting. This is to ensure the film is sufficiently stuck to the glass and where print has been applied, that the ink has properly cured.

Cleaning solutions and materials:

- 1) Most glass cleaners can be used.
- 2) To avoid abrasion always ensure the film is wet when cleaning.
- 3) To avoid abrasion, use a soft cloth or sponge for cleaning and a rubber squeegee for drying.
- 4) NB: It is recommended that abrasive products such as wire brushes, or wire sponges are not used.



Isle of Man
Head Office - Export Sales
Millennium Park Studio
Ballafletcher Road | Douglas
Isle of Man | IM4 4QJ
United Kingdom

UK Office
Sales & Operations
Offices 21/22 Basepoint
Bromsgrove Technology Park
Worcestershire | B60 3ET
United Kingdom

tel: +44 (0)1527 888999
email: sales@digiglass.com

digiglass.com